

Laser Ball Putting Instructions

Putting Indoors:

Aiming the Laser Ball indoors

- Place the Laser Ball on the small clear stand.
- Turn the Laser Ball on.
- Rotate the Laser Ball until the laser is perpendicular to the ground.
- Turn the Laser Ball off.
- Aim at your target of choice turning the clear stand, thereby turning the laser. Turn the laser on to determine how accurate you have aimed.
- Repeat at different lengths until accurate aiming is accomplished.

Aiming your putter indoors

- Place the Laser Ball on the large clear stand with the black line facing up.
- Turn on the laser and rotate the Laser Ball until the laser is perpendicular to the ground.
- Aim the laser at your target of choice - a line of balls or the hole on a putting mat.
- Place a golf ball about eighteen inches in front of the stand with the red laser cutting the ball in half.
- Turn the laser off.
- Place your putter behind the ball and aim at your target.
- Turn the laser on using the C button (found on the remote control) to check your accuracy. Correct any deviation from square.
- With the laser still on, aim. Then, wait for the laser to turn off - this will take approximately four seconds.
- After the laser is off observe what proper aim is and then repeat until satisfied.
- Practice at different distances.

Returning to square indoors

- Place the Laser Ball on the large clear stand with the black line facing up.
- Rotate the laser until it is perpendicular to the ground and striking your target.
- Place a golf ball about twelve inches in front of the stand with the laser cutting the ball in half.
- Place your putter behind the ball and align the putter using the red laser line as a reference.
- Putt the ball and observe if the ball strikes the intended target. Also observe if the surface is flat by watching the way the laser strikes the ball on its way to the target.

Putting Outdoors:

Aiming the Laser Ball outdoors

- Place the Laser Ball on the small clear stand.
- Turn the laser on and rotate the laser downward until you can see the red laser on the ground.
- Select a white target - the Laser Ball sleeve, a line of golf balls, or the include target.
- Aim the black line at your target and slowly rotate the ball upwards until you see the red laser perpendicular on your target.
- Turn the laser off.
- Aim the Laser Ball by turning the clear stand from a kneeling position. Step back and confirm your aim by turning on the laser – thus allowing you to check your accuracy.

Aiming the putter outdoors

- Place the Laser Ball on the large clear stand with the black line facing down.
- Rotate the Laser ball down until the red laser is seen on the green just in front of the stand.
- Slowly rotate the laser up until you see the laser strike your target. This does require practice, as the laser will not be very bright during daylight hours.
- Place a ball about twelve inches in front of the stand with the laser cutting the ball in half.
- Turn the laser off.
- Place your putter behind the ball. Align your putter and turn the laser on using the C button (found on the remote control).
- Check your alignment using the red laser and wait for the laser to turn off, this will take approximately 4 seconds. When the laser turns off you will be able to observe exact alignment.

Returning to square outdoors

- Place the Laser Ball on the large clear stand with the black line facing down.
- Rotate the laser down until you can see the laser on the green.
- Slowly rotate the laser up until you can see it strike your white target of choice.
- Place a ball about twelve inches in front of the stand with the laser cutting the ball in half.
- Place your putter behind the ball and align the putter using the red laser as a reference.
- Putt the ball and observe if the ball strikes the target.

Practicing breaking outdoors

- This technique requires patient and motivation to truly improve your ability to practice the art of reading the green and pace.
- Choose a breaking putt.
- Select the provided target and place behind the hole using four tees. Make sure the target is positioned to funnel missed putts into the hole.
- Place the Laser Ball on the large clear stand with the black line facing down and aim at the place on the target that takes into account the break you wish to allow.
- Place your putter and ball in the red laser line; align your putter and putt. If you have read the green and hit the appropriate pace you will make the putt. If you miss, adjust your pace and try until successful making the putt.
- Change your aim point and try to make the first putt every time – once you have perfected this you will have mastered pace and reading the green.
- Try different length putts and small and large breaking putts to hone your skills.